

# Optimization

## Disable Desktop Booting

`raspi-config` > 1 System Options > S5 Boot / Auto Login

## Limit GPU Memory to 16B

`raspi-config` > 4 Performance Options > P2 GPU Memory

## Disable HDMI

Edit `/etc/rc.local`

```
/usr/bin/tvservice -o  
exit 0
```

## Disable Bluetooth

```
sudo systemctl disable hciuart  
systemctl disable bluetooth.service
```

Edit `/boot/config.txt`

```
dtoverlay=disable-bt
```

## Disable Onboard LED

Edit `/boot/config.txt`

```
dtparam=pwr_led_trigger=none  
dtparam=pwr_led_activelow=off  
  
dtparam=act_led_trigger=none  
dtparam=act_led_activelow=off
```

---

Revision #3

Created 2 February 2024 13:20:58 by Admin

Updated 2 February 2024 13:29:55 by Admin