



Place this call through: Custom - elastix

Failover: None

PIN Set: ??

Dialing Rules: If the number begins with [5] and followed by ( [ ] more than) [2] digits.

Delete [ ] digits from the front and auto-add digit [ ] before dialing.

**?? Elastix**

// ?? Trunk???? Trunk ???Outgoing Settings ??? Elastix -> IPX08 ?????Incoming Setting ??? IPX08 -> Elastix ?  
???

PBX > PBX Configuration > Trunks

Outgoing Settings:

Trunk Name: ???

Peer Details:

host=ipx08.ip.address  
username=fromelastix  
secret=thisispassword  
type=peer

Incoming Settings:

USER Context: fromipx08

USER Details:

host=ipx08.ip.address  
secret=thisispassword  
type=user  
context=from-internal

Register String: ??

Tips:

? outgoing settings ? username ??? ipx08 ?? peer trunk ? username ???

// ?? outbound route

PBX > PBX Configuration > Outbound Routes

Route Name: ???

Dial Patterns: 1XX

Trunk Sequence: IAX2/<TrunkName>