



?????

- Mainboard: ASUS P8H67

?????

- PIAF v1755 (CentOS 5.5 Linux)

????????? cdrom:/ks.cfg ????

???????

1. ?? BIOS ? STAT mode ? IDE -> AHCI
2. ?? AHCI ???????? IDE mode ?????????????? boot ??????
boot: linux ks=cdrom:ks.cfg pci=nommconf all-generic-ide irqpoll

????????????????Kernel Panic

?? BIOS ?? SATA mode: IDE???????????????? Linux ?????????? e??? kernel ???????????

kernel pci=nommconf all-generic-ide irqpoll

???????????????????? /boot/grub/menu.lst ??????????????????????

????

- [CentOS ?? SATA ??? IDE ?????? AHCI](#)
- [SATA????CentOS?????](#)
- [Using PiaF with SATA...](#)