

Lsi ?Dell,IBM,HP oem ??????. ?????????????? Dell Perc ??  
??? 5i ,5i/r ,5e , 6i ,6i/r ,6e

Del l Perc 5i 5E ? 1068 Roc (Raid on chip)  
Dell perc 6i 6E ? 1078 Roc ?? Dell 6ir???LSI 1068

??Roc firmware driver ??????? ???? ??????Lsi .

PID  
5E VEN\_1028&DEV\_0015  
5I VEN\_1028&DEV\_0015  
6E VEN\_1000&DEV\_0060  
6i VEN\_1000&DEV\_0060

5i/5E FW?[LSI MegaRAID SAS 8408E Drive](#)?????LSI????????? -NoSigChk -NoVerChk  
6i/6E FW?[LSI MegaRAID SAS 8888ELP](#)

Dell???Drive 5&6?????????  
?????????LSI?MegaRAID Storage Manager&CLI(MSM and CLI)  
Drive????www.dell.com.tw????  
XP [Drive?????http://www.ossllab.com.tw/.../=5i\\_6i\\_xp.rar](http://www.ossllab.com.tw/.../=5i_6i_xp.rar)

????? LSI ?BIOS?????:

1.???http://www.[lsi.com](#)/storage\_home/products\_home/internal\_raid/megaraid\_sas/  
megaraid\_sas\_8344elp/index.html

- ?? 1.MegaCLI - Windows? +Driver ???DOS ?MegaCli
- 2.????FIRMWARE
- 2.????????????????????
- 3.??WINDOWS??CMD MODE? (?????) ???DOS ?????megacli dos?
- 4.????MEGACLI ???FIRMWARE????
- 5.?? MegaCli -adpfwflash -f XXXX.rom -a0
- 6.?ENTER ?????????????????????????????
- 7.??2~3????????
- ?: XXXX.rom =>XXXX???rom??