

??????

- [3G USB Modem ??](#)
- [Debian on NextVOD](#)
- [Internet Radio](#)
- [STLinux Cross-Compile Enviroment](#)
- [U-Boot](#)
- [USB ?????](#)
- [?? Asterisk GUI ????](#)

**[v0.3][??] ?? IP ????**

?? /etc/init.d/rcSBB

```
# Enable DHCP Client for ethernet
#/sbin/udhcpc &
# Enable static IP for ethernet
/sbin/ifconfig eth0 192.168.6.10 netmask 255.255.255.0
/sbin/route add default gw 192.168.6.1
```

**[v0.3][??] ?? sftp ??**

?? /etc/openssh/sshd\_config

```
#Subsystem sftp /usr/libexec/openssh/sftp-server
Subsystem sftp internal-sftp -f AUTH -l INFO
```

**[v0.3][??] ntpdate ??????????**

?? /etc/init.d/rcSBB

```
...
# Enable DHCP Client for ethernet
/sbin/udhcpc &
sleep 10 <==== ?????
```

```
# Sync the time
/etc/init.d/ntpdate start
...
```

**[v0.1][??] Telnet ?????/??????**

?? /etc/init.d/rcSBB

```
...
/usr/sbin/telnetd -l /bin/login
...
```

?? /etc/shadow???? root ??

touch /etc/shadow  
passwd root

????????

?? LED ??

<http://rexct.blogspot.tw/2013/08/led.html>

?? kernel

Device Drivers

- GPIO Support
  - ? /sys/class/gpio/... (system interface)