



?? sh linux ? kernel (vmlinux.ub)

????????????? Ubuntu 8.04

????

- [?? Kernel - linux-sh4-2.6.32.59 stm24 0211](#)

?? kernel ??????

<http://code.google.com/p/nexttv-mod/downloads/list>

Kernel ???linux-sh4-2.6.23.17\_stm23\_A18B

?? vmlinux

????????????????????

????????????????? .config?????????????

??????

```
cd /home/alang/STLinux/build_source/linux-sh4-2.6.23.17_stm23_A18B/linux-sh4-2.6.23.17_stm23_A18B
make ARCH=sh CROSS_COMPILE=sh4-linux-pdk7105_defconfig
make ARCH=sh CROSS_COMPILE=sh4-linux- vmlinux
```

TIPS:

- ?????????? .config ??????????????

- ?????????????????? -j4?????????

- ?????????? (????????? make distclean??? .config\* ????????)

make clean

rm vmlinux.\*

- ?????????????????? make menuconfig ??? .config????????????? .config ?

- ??????????????????????????:

1. ?? .config

2. ?? make menuconfig?????????????????

3. ?? .config ??????????????????????

4. ?? .config ??????????????

????

make ARCH=sh CROSS\_COMPILE=sh4-linux- modules

make ARCH=sh CROSS\_COMPILE=sh4-linux- modules\_install INSTALL\_MOD\_PATH=./modules\_install

TIPS?

INSTALL\_MOD\_PATH ??????????

?? vmlinux.ub

????? <http://www.stlinux.com/u-boot/mkimage/kernel-images>

sh4-linux-objcopy -O binary vmlinux vmlinux.bin

gzip --best --force vmlinux.bin

mkimage -A sh -O linux -T kernel -C gzip -a 0x80800000 -e 0x80801000 -n "Linux 2.6" -d vmlinux.bin.gz vmlinux.ub

TIPS:

?????? gzip, mkimage ??????? apt-get ??

???Ubuntu 8.04 ??? uboot-mkimage ???

Q&A

Q: ?????? APP ??? kernel source????

???? kernel source ???

- kernel-source
  - ? /usr/src/2.6.23.17\_stm23\_A18B-PDK7105-32BITS-A18B
- kernel-modules
  - ? /lib/modules/2.6.23.17\_stm23\_A18B-PDK7105-32BITS-A18B
  - ? /lib/modules/2.6.23.17\_stm23\_A18B-PDK7105-32BITS-A18B/build -> /usr/src/2.6.23.17\_stm23\_A18B-PDK7105-32BITS-A18B
  - ? /lib/modules/2.6.23.17\_stm23\_A18B-PDK7105-32BITS-A18B/source -> /usr/src/2.6.23.17\_stm23\_A18B-PDK7105-32BITS-A18B

Q: ??? /dev/sda3 ? rootfs

1. ?? kernel ??? .config ??
  - CONFIG\_CMDLINE\_OVERWRITE=y
  - CONFIG\_CMDLINE="console=ttyAS0,115200 root=/dev/sda3 rootfstype=ext3 rw nwhwconf=device:eth0"
2. ?? U-Boot ??? /dev/sda2 ? rootfs???? U-Boot ??????? vmlinux.ub ?? /dev/sda2 ? /dev/sda3?
3. nwhwconf ??????????????
4. ??? MAC address ?????????????????????? DHCP ?????????????????? IP ??????

Q: ?? 256 MB Memory

System type -> Memory management options ->

- Physical memory size = 0x20000000

Q: CPU ???

System type -> CPU Frequency scaling ->

- 'conservative' cpufreq governor

??????

```
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_cur_freq
```

??

```
echo "conservative" > /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor
```

????

- [??????? Kernel](#)