

???? SIP Provider/VoIP Gateway?? Trunk ????????????????? Trunk ?? [Web-UI: ?](#)  
[?????](#)

- Pennytel . . . . . 2**
- Chief070 - ????. . . . . 2**
- Dell Voice . . . . . 3**
- IPBB - ????. . . . . 4**
- Q & A . . . . . 4**

## Pennytel

- FromUser: <SIP Number> ????????????????

The screenshot shows a configuration window titled "Edit SIP trunk trunk\_2". The fields are as follows:

- Provider Name: pennytel
- Hostname: sip.pennytel.com
- Username: 8883963939
- Password: [Redacted]
- Codecs: First: u-law, Second: a-law, Third: None, Fourth: None, Fifth: None
- CallerID: [Empty]
- FromDomain: [Empty]
- FromUser: [Empty]
- AuthUser: [Empty]
- insecure: very
- Outbound Proxy: [Empty]
- Enable Remote MWI:

Buttons at the bottom: Cancel, Save

## Chief070 - ????

## Trunks

- Password: ?????? SIP ??
- Codec: ?????? g729 codec????? u-law ???
- Outbound Proxy: 202.133.231.17 (??????? IP)

**Edit SIP trunk trunk\_3**  
 Provider Name: chief070  
 Hostname: chiefcall.com.tw  
 Username: 070101XXXXXX  
 Password:   
 Codexes: First: u-law Second: a-law Third: None  
 Fourth: None Fifth: None  
 CallerID:   
 FromDomain: chiefcall.com.tw  
 FromUser: 070101XXXXXX  
 AuthUser:   
 insecure: very  
 Outbound Proxy: 202.153.167.4  
 Enable Remote MWI:

?? sip.conf

Web-UI > File Editor (Advanced Mode) > sip.conf > Add Context > Add New Context: chief-did

host=202.133.231.17

type=peer

context=DID\_trunk\_3

NOTE:

DID\_trunk\_# ??? # ??? Trunks ??????????????(???)?

**OSSLab**  
<http://www.osslab.com.tw/>  
 File Editor sip.conf New File  
 sip.conf Add Context  
 + [general]  
 + [authentication]  
 - [chief-did]  
 host=202.153.167.4  
 type=peer  
 context=DID\_trunk\_3

Dell Voice

?? SIP Unlock key?

password: ????????????

The screenshot shows a configuration window titled "Edit SIP trunk trunk\_1". The fields are as follows:

- Provider Name: dellvoice
- Hostname: sip.fongo.com
- Username: 143 [blurred]
- Password: [empty]
- Codecs: First: u-law, Second: a-law, Third: None, Fourth: None, Fifth: None
- CallerID: 143 [blurred]
- FromDomain: sip.fongo.com
- FromUser: 143 [blurred]
- AuthUser: [empty]
- insecure: very
- Outbound Proxy: proxy.fongo.com
- Enable Remote MWI:

Buttons: Cancel, Save

IPBB - ????

- Username: <070??>
- Password: <SIP ??>
- FromUser: <070??>

The screenshot shows a configuration window titled "Edit SIP trunk trunk\_3". The fields are as follows:

- Provider Name: ipbb
- Hostname: msw1.mky.com
- Username: [blurred]
- Password: [blurred]
- Codecs: First: u-law, Second: None, Third: None, Fourth: None, Fifth: None
- CallerID: [empty]
- FromDomain: msw1.mky.com
- FromUser: [blurred]
- AuthUser: [empty]
- insecure: very
- Outbound Proxy: [empty]
- Enable Remote MWI:

Buttons: Cancel, Save

**Q & A**

Q: [??] ??/????????????????

WARNING[428] chan\_sip.c: Forbidden - wrong password on authentication for REGISTER for '070101XXXXX' to 'chiefcall.com.tw'

A: ????????? IP ????????? 5 ???

Q: [??] ????????

WARNING[1271] chan\_sip.c: Retransmission timeout reached on transmission 2e4415d7-c2a5ca44@192.168.1.26 for seqno 101 (Critical Response) -- See <https://wiki.asterisk.org/wiki/display/AST/SIP+Retransmissions>  
Packet timed out after 44019ms with no response

A: ?????? Apply Changes ???