

????

- CentOS 6.9 x86\_64
- MegaRAID Manager 14.05.02-03 (ibm\_utl\_msm\_14.05.02.03\_linux\_32-64.bin)

????

?????

```
chmod u+x
mkdir IBM_MSM
./ibm_utl_msm_14.05.02.03_linux_32-64.bin -x IBM_MSM/
```

??????????:

```
.
??? IBM_MSM
? ??? 32bit
? ??? 64bit
? ??? install.sh
? ??? readme.txt
??? ibm_utl_msm_14.05.02.03_linux_32-64.bin
```

???????

```
yum install libstdc++ compat-libstdc++-33 libXau libxcb libX11 libXext libXi libXtst net-snmp
net-snmp-utils lm_sensors
```

?? MegaRAID

```
cd IBM_MSM/64bit
./install.csh
```

The provisions of Sections 2, 3, 4, 7, 8 and 9 shall survive any termination of this Agreement.

Press Y to accept the License Agreement : Y <==

The options are :

- a The Complete Installation of MegaRAID Storage Manager (MSM)
- c The Client components only program of MSM
- s The StandAlone component of MSM
- l The Local component of MSM
- d

The Sever component of MSM

au

The upgrade only option for Complete MSM

cu

The upgrade only option for Client only MSM

su

The upgrade only option for Standalone MSM

lu

The upgrade only option for Local MSM

du

The upgrade only option for Server MSM

u

The upgrade only option for MSM

Setup Type :3 <=== ?? StandAlone ????? 3

????

??????

cp /usr/local/MegaRAID\ Storage\ Manager/MSMStartupUI.desktop.redhat /root/Desktop/  
MSMStartupUI.desktop

??????????