

- [iSCSI Boot](#)
- [Cisco Nexus 5000 ??](#)
- [iSCSI ??](#)
- [DESIGN ISCSI SERVER](#)
- [iSCSI \(Internet SCSI\) ??](#)
- [iSCSI Linux initiator](#)
- [StarWind iSCSI SAN Software](#)
- [Toe](#)
- [Windows Initiator](#)

?? 11, 2007 ??? sunchiahome

**Step 0: ??**

**Step 1: ?? iSCSI target**

**Step 2: ?? iSCSI target**

**Step 3: iSCSI Target???**

**Step 4: ?? iSCSI target ??????**

**Step 5: iSCSI Target tools**

**Step 6: manpages**

**Step 7: iSCSI initiator**

**Step 8: ??????**

**Step 0 : ??**

????????? iSCSI

iSCSI(Internet SCSI)?? IP-based ???????. iSCSI ??? SAN???? SAN????????? Server ??????.????? Server ??????

?????.?????????????. iSCSI ? 2003?2?????? IETF ?????.

iet(iSCSI Enterprise Target)

### Step 1: ?? iSCSI target

??????iSCSI Target ?????? <http://iscsitarget.sourceforge.net/> ?????.

???????? kernel ??,????????????????.

? RHEL 4 ???? kernel 2.6.9 ,????????????? iscsi-target-0.4.00.

Fedora Core 5 ???? kernel 2.6.15 ,????????????? iscsi-target-0.4.13.

????????????? linux ?????????????.

```
[root@unsvr root]# uname -a
```

### Step 2: ?? iSCSI target

?????? kernel-devel-version ?????????.

```
[root@unsvr root]# rpm -ivh /media/cdrom/Fedora/RPMS/kernel-devel-version
```

????????? <http://kernel.org> ????????? kernel

??? iscsitarget ?????????????.

```
[root@unsvr root]# tar xvfz iscsitarget-version.tar.gz
```

```
[root@unsvr root]# cd iscsitarget-version
```

????????????? kernel-devel-version ?????????????.

```
[root@unsvr iscsitarget-version]# make KERNELSRC=/usr/src/kernels/2.6.14-1.1526_FC4-i686
```

```
[root@unsvr iscsitarget-version]# make install
```

???? iscsi Target?.

???? fireware ??,??? port 3260 ??(iSCSI ?? port 3260).

### Step 3 : iSCSI Target???

????????? iSCSI Target ???,????? /root/iscsitarget-version/etc/inetd.conf

```
[root@unsvr iscsitarget-version]# cp etc/ietd.conf /etc
```

????????? /etc/ ???.

????????????????.

```
[root@unsvr iscsitarget-version]# vi /etc/ietd.conf
```

-----

Target iqn.2001-04.com.example:storage.disk2.sys1.xyz

# Users, who can access this target

# (no users means anyone can access the target)

IncomingUser joe

#OutgoingUser

# Lun definition

# (right now only block devices are possible)

Lun 0 Path=/dev/sdb,Type=fileio

Lun 1 Path=/dev/sdc,Type=fileio

# Alias name for this target

# Alias iSCSI

# various iSCSI parameters

# (not all are used right now, see also iSCSI spec

-----  
??:

Target iqn.2001-04.com.example:storage.disk2.sys1.xyz

???? iSCSI Target ????????

IncomingUser joe

?? iSCSI Initiator ?????????? Disk,??????????.

Lun 0 Path=/dev/sdb,Type=fileio

Lun 1 Path=/dev/sdc,Type=fileio

??? joe ??????????,????? sdb,sdc.???? LUN(Logic Uit Number)????? iSCSI Initiator ?????????.

?????(hda,sda... ?)??????? LVM?????.?? SAN ???? "??????????????? Server??,??????????????"

?? LVM ?????????.

LVM-??

LVM(Logical Volume Manager)????????????????,????????????????.

LVM-??

Linux ?????????????? LVM.

LVM-RAID0

LVM(Logical Volume Manager) ???? RAID0(striping)???

LVM-snapshots

?? LVM(Logical Volume Manager) ? Snapshots ???????

**Step 4: ?? iSCSI target ??????**

????????? IP ,????????? IP.?? iSCSI target ???IP? 10.6.116.108.

[root@unsvr root]# netconfig -device eth0

?????iSCSI Target,???????

[root@unsvr root]# service iscsi-target start

???????????????? iSCSI Target,???????

[root@unsvr root]# chkconfig iscsi-target on

????????? IP SAN ????

### Step 5: iSCSI Target tools

ietd(iSCSI Enterprise Target Daemon) ??????????.

1.ietd

2.ietadm

### Step 6: manpages

?????????? make install ?,????? manpages ?????????? /usr/share/man/ ?,???????????????? manpages ?? /usr/share/man.

[root@unsvr iscsitarget-version]# gunzip doc/manpages/ietd.conf.5

[root@unsvr iscsitarget-version]# gunzip doc/manpages/ietd.8

[root@unsvr iscsitarget-version]# cp doc/manpages/ietd.conf.5.gz /usr/share/man/man5

[root@unsvr iscsitarget-version]# cp doc/manpages/ietd.8.gz /usr/share/man/man8

```
[root@unsvr iscsitarget-version]# man ietd.conf
```

```
[root@unsvr iscsitarget-version]# man ietd
```

**Step 7: iSCSI initiator**

?? initiator ?????? iSCSI target ??,???????

[I.iSCSI\(Linux initiator\)](#)

[II.iSCSI\(Windows initiator\)](#)

-