

chan_mobile

Set Up Bluetooth on Linux

? Gemprowireless VoIP Gateway ??

Install packages

```
# For RedHat
yum install bluez bluez-tools

# For Debian/Ubuntu
apt-get install bluetooth bluez
```

Service bluetooth

```
# For RedHat
systemctl restart bluetooth
systemctl status bluetooth
```

Pair the BT devices

“ ?????????????? Gemprowireless Gateway ??????

```
bluetoothctl

[bluetooth]#
Controller 00:1A:7D:DA:71:13
[Name: freepbx.sangoma.local
[Alias: freepbx.sangoma.local
[Class: 0x000104
[Powered: no
[Discoverable: no
[Pairable: no
```

```
❑UUID: Generic Attribute Profile (00001801-0000-1000-8000-00805f9b34fb)
❑UUID: A/V Remote Control      (0000110e-0000-1000-8000-00805f9b34fb)
❑UUID: PnP Information          (00001200-0000-1000-8000-00805f9b34fb)
❑UUID: Generic Access Profile  (00001800-0000-1000-8000-00805f9b34fb)
❑UUID: A/V Remote Control Target (0000110c-0000-1000-8000-00805f9b34fb)
❑Modalias: usb:v1D6Bp0246d052C
❑Discovering: no
```

```
[bluetooth]# power on
```

```
[bluetooth]# agent on
```

```
[bluetooth]# scan on
```

```
[bluetooth]# devices
```

```
Device 00:19:5D:3E:01:77 GP-712-1
```

```
Device 00:19:5D:24:C6:98 GP-712-2
```

```
[bluetooth]# pair 00:19:5D:3E:01:77
```

```
...
```

```
...
```

```
[agent] Enter PIN code: 0003
```

```
[CHG] Device 00:19:5D:3E:01:77 UUIDs: 00001108-0000-1000-8000-00805f9b34fb
```

```
[CHG] Device 00:19:5D:3E:01:77 UUIDs: 0000111e-0000-1000-8000-00805f9b34fb
```

```
[CHG] Device 00:19:5D:3E:01:77 ServicesResolved: yes
```

```
[CHG] Device 00:19:5D:3E:01:77 Paired: yes
```

```
Pairing successful
```

```
[bluetooth]#
```

```
[bluetooth]# paired-devices
```

```
Device 00:19:5D:3E:01:77 GP-712-1
```

Set Up Asterisk

```
[root@freepbx ~]# asterisk -rx "module show like chan_mobile"
```

Module	Description	Use Count	Status	Support Level
chan_mobile.so	Bluetooth Mobile Device Channel Driver	0	Not Running	extended
1 modules loaded				

Create `/etc/asterisk/chan_mobile.conf` :

[general]

interval=30 ; Number of seconds between trying to connect to devices.

; The following is a list of adapters we use.

; id must be unique and address is the bdaddr of the adapter from hciconfig.

; Each adapter may only have one device (headset or phone) connected at a time.

; Add an [adapter] entry for each adapter you have.

[adapter]

id=usbbt1

address=00:1A:7D:DA:71:13

;forcemaster=yes ; attempt to force adapter into master mode. default is no.

;alignmentdetection=yes ; enable this if you sometimes get 'white noise' on asterisk side of the call

no ; its a bug in the bluetooth adapter firmware, enabling this will compensate for it.

no ; default is no.

; The following is a list of the devices we deal with.

; Every device listed below will be available for calls in and out of Asterisk.

; Each device needs an adapter=xxxx entry which determines which bluetooth adapter is used.

; Use the CLI command 'mobile search' to discover devices.

; Use the CLI command 'mobile show devices' to see device status.

;

; To place a call out through a mobile phone use Dial(Mobile/[device]/NNN.....) or Dial(Mobile/gn/NNN.....) in your dialplan.

; To call a headset use Dial(Mobile/[device]).

[GP712P1]

address=00:19:5D:3E:01:77 ; the address of the phone

port=1 ; the rfcomm port number (from mobile search)

context=incoming-mobile ; dialplan context for incoming calls

adapter=usbbt1 ; adapter to use

group=1 ; this phone is in channel group 1

;sms=no ; support SMS, defaults to yes

;nocallsetup=yes ; set this only if your phone reports that it supports call progress notification, but does not do it. Motorola L6 for example.

bluetoothctl (optional)

Available commands:

```
list
show [ctrl]
select <ctrl>
devices
paired-devices
system-alias
connect <address>
disconnect
remove <address>
power <on/off>
mode <mode>
agent <on/off/capability/timeout>
default-agent
scan <on/off>
pairable <on/off>
pair <address>
discoverable <on/off>
info <address>
menu <command>
quit
```

Other commands

```
# Listing all known devices
```

```
[bluetooth]# devices
```

```
# Powering the Bluetooth controller on or off
```

```
[bluetooth]# power on
```

Pairing with a device

```
[bluetooth]# pair <mac_addredd>
```

Remove a device

```
[bluetooth]# remove <mac_address>
```

Connecting to a paired device

```
[bluetooth]# connect <mac_address>
```

Disconnecting from a paired device

```
[bluetooth]# disconnect <mac_address>
```

Revision #12

Created 10 August 2024 11:32:49 by Admin

Updated 10 August 2024 17:13:58 by Admin