





## ?? SELinux

```
sed -i 's/SELINUX=.*$/SELINUX=disabled/' /etc/selinux/config
setenforce 0
```

?????

```
systemctl stop firewalld.service
systemctl disable firewalld.service
```

???????

## ?? IPMI (BMC) ??

???????????? IPMI Network Port  
??????? > Petitboot > Exit to Shell

```
ipmitool lan print 1
ipmitool lan set 1 ipsrc static
ipmitool lan set 1 ipaddr <ipmi-ip-address>
ipmitool lan set 1 netmask <ipmi-ip-netmask>
ipmitool lan set 1 defgw ipaddr <ipmi-ip-gateway>
ipmitool lan print 1
```

## BMC ?????

“ http://ipmi-ip-address/ , ?????: ADMIN / ADMIN  
NOTE: ?????????????????????????????????

Java ??? 1.6.0.45 32-bit, Windows 7 64-bit??????? Java ???

## IPMITools ????? ipmitool ? Desktop PC

## Ubuntu

```
sudo apt-get update
sudo apt-get install ipmitool
```

? source ?????

```
wget https://sourceforge.net/projects/ipmitool/files/latest/download
bzip2 -d ipmitool-1.8.15.tar.bz2
tar xvf ipmitool-1.8.15.tar
cd ipmitool-1.8.15
./configure
```

????

```
ipmitool -I lanplus -H ipmi-ip-address -U ADMIN -P ADMIN fru
```

????????????

sdb	EMPTY	NVMe	EMPTY
sde	sdc	EMPTY	EMPTY
sda	sdd	EMPTY	NVMe

---

Revision #5  
 Created 2022-03-09 02:16:33 CST by A-Lang (Admin)  
 Updated 2022-03-09 13:35:57 CST by A-Lang (Admin)